

X100P

Clamp-On

Portable Ultrasonic Flowmeter



Instruction Manual

Table of Content

Delivery Items	4
Overview	6
Control and Display	8
Quick Installation	Errore. Il segnalibro non è definito.
Setting Operation - Initial Setting	13
Setting Operation – Pipe Specification	18
Setting Operation – Liquid Characteristics	21
Setting Operation – Installation	23
Setting Operation – Operating Condition	28
Setting Operation – Flow Parameters	32
Input/output – Analog Out [1]&[2]	34
Input/output – Relay Out [1]&[2]	36
Input/output – Analog In [1]&[2]	Errore. Il segnalibro non è definito.

Data Logger	Errore. Il segnalibro non è definito.
Diagnostics Menu	45
Drawing.....	47

Delivery Items


Flow Computer



Transducer



Mounting Track



Easy Track



Magnetic Track

EUROMAG INTERNATIONAL S.r.l. www.euromag.com | www.euromagdata.com

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
Tel. +39 049.9005064 | Fax +39 049.9007764
euromag@euromag.com | euromag@pec.it

P.IVA 02161920281 C.F. 01908330242
N. CEE IT 02161920281, C.C.I.A.A. di Padova,
Cap. Soc. € 98.900 i.v., R.E.A. n 211936



Cable



EUROMAG INTERNATIONAL S.r.l. www.euromag.com | www.euromagdata.com

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
Tel. +39 049.9005064 | Fax +39 049.9007764
euromag@euromag.com | euromag@pec.it

P.IVA 02161920281 C.F. 01908330242
N. CEE IT 02161920281, C.C.I.A.A. di Padova,
Cap. Soc. € 98.900 i.v., R.E.A. n 211936



Overview

Introduction

Xonic-100P is a Portable type Ultrasonic Flowmeter, whose transducers could be mounted on any material of pipes. Xonic-100P allows Easy Measurement of flow rate in pipes by installing transducers on the outside of pipes. The latest electronics and DSP (Digital Signal Processing) Technologies enable the Instrument with convenient solution accurately measure system flow rates without breaking or opening the pipes.

Application

- Water Supply, Drainage, Water Purification Facility (Clean Water, Municipal Water, Waste Water, Manure and Etc.)
- Oil Filed and Petrochemical Plants (Cruder Oil, Diesel, Alcohol, and Etc.)
- Food and Beverage Plants (Acids, Benzene, Milk, Beer and Etc.)
- Steel Factory and Mining Industries (Lime Stone Slurries, De-Ionized Water and Etc.)
- Power Plants

Features

- Patented AR Mode (Anti-Round)
- DSP Function
- Cross Correlation FFT
- Oscilloscope Function
- 20 Hours Operation with Batteries
- Submersible Connectors

Specifications

- Type : Clamp-On Ultrasonic Flowmeter (Portable Type)
- Principle : Transit-Time
- Pipe Size : 12.7 ~ 6000 mm
- Accuracy :
 - ± 1.0 % (single path)
 - ± 0.5 % (dual path)
- Flow Velocity: $\pm 0.02 \sim 12.0$ m/s
- Turn-Down Ratio: 1000:1
- Damping: 1 ~ 999 seconds.
- Repeatability: 0.25%
- Required Straight Run:
 - Upstream 10D, Downstream 5D (single path)
 - Upstream 7D, Downstream 3D (dual path)
- Output :

EUROMAG INTERNATIONAL S.r.l. www.euromag.com | www.euromagdata.com

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
 Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
 Tel. +39 049.9005064 | Fax +39 049.9007764
euromag@euromag.com | euromag@pec.it

P.IVA 02161920281 C.F. 01908330242
 N. CEE IT 02161920281, C.C.I.A.A. di Padova,
 Cap. Soc. € 98.900 i.v., R.E.A. n 211936



- One 4-20mADC for flow
- One Relay for Total
- RS-232C for Communication
- Data Logger : 8 Mbytes (above 500,000 times)
- Display : Graphic Color LCD
(Flow, Total, Velocity, Delta T, Ultrasonic Signal Shape, Frequency)
- Temperature :
 - Electronic : -20°C ~ +120 °C
 - Transducer : -40°C ~ +120 °C
- Power Battery : with 110 ~ 220 VAC power adaptor
- Enclosure : NEMA 4 (IP67)
- Transducer : NEMA 7 (IP68, Water Proof)

Identification of Product

On the right side of flowmeter, there is a silver sticker with per product's S/N.
This is Identification of the product.

Ultrasonic Flowmeter X 100P	
P/N: Xonic-100	V/M: 3.1.0
S/N: C10184	AC110~220V

Control and Display

EUROMAG INTERNATIONAL S.r.l. www.euromag.com | www.euromagdata.com

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
Tel. +39 049.9005064 | Fax +39 049.9007764
euromag@euromag.com | euromag@pec.it

P.IVA 02161920281 C.F. 01908330242
N. CEE IT 02161920281, C.C.I.A.A. di Padova,
Cap. Soc. € 98.900 i.v., R.E.A. n 211936




Instructions– Installation Quick Setup

The Clamp-On type Ultrasonic Flowmeter Xonic-100P allows the simplest and the easiest installation of any material of pipes. In order to ensure accurate and reliable measurement of flow is needed. In this section, you will know how to select the mounting place, mounting method and etc. To active the flow measurement.

Step 1: Select Mounting Place

Select the right mounting place is the most important thing for ensuring the accuracy. Please according to the follow steps to find the best mounting place:

- 1) Make sure the pipe is full.
- 2) Select a location where is **straight** and allows the pipe run of 10D upstream and 5D downstream.
- 3) Avoid to mounting on a scaled or rusted pipe, both of outer and inner wall can affect the Signal of Ultrasonic flowmeter.




Step 2: Setup Procedure

Before installing the transducer, set the specifications of the pipe in the main menu to allow measurements.

Caution) Measurements cannot be accomplished without these settings.

Please refer to the correspondent Sections to introduce the specifications.


- 1) Press [MENU] to enter MAIN MENU.
- 2) Before install the flowmeter, please make sure to fulfill the procedures blow:
 1. GENERAL
 2. CH SELECT
 3. PIPE
 4. LIQUID




Step 3: Select Mounting Mode

There are 2 types of Mounting Mode, “V mode” and “Z mode”.


[V mode]: Normally, V mode is used as standard for most applications. Because it provides longer signal, so more accurate measurement of flow velocity.



Side View




Vertical View

**Sectional Drawing**

[Z mode] :

Z Mode is recommend when the flow condition is bad. The reason might be cause of scale built up inside the pipe, too thick liner, plastic pipe material and etc. Which can induce a lot of noise into signals. By using Z mode, the signal will straightly be send to transducers and without the possibility of noise induction.

**Side View****Vertical View****Sectional Drawing**

Step 4: Pipe Preparation

Before install the transducer, users must confirm if transducer surface can be coupled to a pipe surface. With an area slightly larger than the flat surface of the transducer must be cleaned to bare metal on the pipe. Remember to remove all scale, rust and paint. Thoroughly dry and clean the mounting surface.

EUROMAG INTERNATIONAL S.r.l. www.euromag.com | www.euromagdata.com


Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
Tel. +39 049.9005064 | Fax +39 049.9007764
euromag@euromag.com | euromag@pec.it

P.IVA 02161920281 C.F. 01908330242
N. CEE IT 02161920281, C.C.I.A.A. di Padova,
Cap. Soc. € 98.900 i.v., R.E.A. n 211936



Step 5: Mounting Space

**Please review the section carefully. The measurement could be failed by incorrect installation.*
 After introducing all of data to the flowmeter, the system will calculate the precision distance that must be kept between two transducer. The information will show at the menu, **5.6 INSTALL INFO** and **3.0 SENSOR DISTANCE**. This Mounting Space is calculated by the setup data, like the application, pipe size, pipe material and etc. Therefore, different cases have different distances needed to keep. (from surface to surface)




INSTALL	INSTALL INFO
1. SENSOR TYPE	PIPE:STEEL
2. SAMPLING CLK	-OD: 165.20mm
3. MOUNT TYPE	-T: 5.00m
4. INSTALL INFO	Liner:None
5. AUTO INSTALL	-T: 0.00m
6. QUICK INSTALL	Sensor:C type
7. ACTUAL ZERO	-Clk: 20ms
	-Mnt: CLAMP_ON Z
	-SPACE: 65.0mm

Step 5: Install Mounting Track


Install EASY/MAG Mounting Track on the mounting place after remove all scale, rust and paint. Fix the mounting track with the Strap Kits in the packing list. And make sure to tighten the transducer strap securely.

Easy Mounting Track



Step 6: Applying Transducer

Apply a small quantity of couplant (Synthetic Grease) to the bottoms of transducer. After cleaning the surface of the pipe, the transducers should be mounted into the mounting track.



↑ Couplant


Instructions – Data Logger

Step 1: Plugin the Cable

Use the RS-232C Communication Cable to output the data.

Step 2: Log Enable

- [MENU] – 8. DATA LOG – 2. RS-232C – 7. LOG ENABLE – **2. ENABLE**.



Step 3: Download DNW.exe

Download the software in user's Laptop.


Caution) Please contact the manufacture for the software.

- DNW allows user to:
1. Output the logger data
 2. Upgrade flowmeter




Step 4: Laptop's Port Setup


- Open the "Device Manager" on user's Laptop.
➤ Find "PORTS (COM & LPT)" and click "**Communications Port**".



- Open the tab, “**Port Settings**” and click “**Advanced**”.



- Feel free to set the COM Port Number to “COM 1/COM 2/COM 3/COM 4”.
(*The software “DNW” works with COM 1~4 only.)




- Then, click “OK” button and close the Device Manager to complete the setting.


Step 5: Setup DNW

Caution) Make sure NOT to turn on flowmeter's power at this step


- Run the Software (DNW.exe) and click “**Configuration**”.




- User will see the window of “UART/USB Options” as below.
- Set the Baud Rate at “115200” and the COM Port that user just set.



- After return to DNW, open the “Serial Port” menu and click “Connect”



- After Connecting, user will see the information which just been setup and shows on the top of the window as figure.




Step 6: Power On

- Press “U” key on Laptop and turn on flowmeter's power **at the same time.**

Step 7: Flowmeter Port Select


- Go to [MENU] – 9. DATA LOG – 3. MEMORY – **6. PORT SELECT**.



- **6. Port Select**
 1. RS232 Port (RS-232C & RS485)
 2. Firmware Port (9-pin Communication Cable)

Step 8: Print Out the Data

- Go to [MENU] – 9. DATA LOG – 3. MEMORY – 1.PRINT – **2. TO 232**.



- **2. TO 232** (Available for all the communication cables.)
 Press [ENT] to output the data. Then, user will see DNW is downloading the data automatically.


Instructions – Initial Setting

1.1 GENERAL - Site Name

User must input Site Name to record the flow data of the site. The name will be registered with other operation setting.

Press [MENU] – 1.GENERAL – 1.SITE NAME

- Move cursor by [◀] [▶].
- Input alphabet characters by [F1]
- Leave the edit mode by pressing [ENT].




1.2 GENERAL - Application

Xonic 100 has multiple applications for our users. User shall sets the application depending on the requirement of the installation site.

Press [MENU] – 1.GENERAL – 2.APPLICATION

- 1. SINGLE CHANNEL (Path):
Use 1 pair of transducer on one pipe.
- 2. DUAL PATH:
Use 2 pair of transducer on one pipe.
- 3. DUAL CHANNEL:
Use 2 pair of transducer on two pipe for increasing the accuracy.




2. Channel Select

User can select Single Channel or Dual Channel in the system.

Press [MENU] – 2.CH SELECT

- 1. Channel 1 (Default)
- 2. Channel 2 (for user whom needs to measure more than 1 site)



Setting Operation – Pipe Specification

3. Pipe -

Before installing the flowmeter, set the specifications of the pipe in the main menu to allow measurements. **Caution) Measurements cannot be accomplished without these settings.**

Press [MENU] – 3.PIPE

MAIN MENU	
MAIN MENU	PIPE
1. GENERAL	1. FLANGE TYPE
2. CH SELECT	2. PIPE UNIT
3. PIPE	3. PIPE MATERIAL
4. LIQUID	4. PIPE SONIC V _s
5. INSTALL	5. PIPE DIAMETER
6. OPERATE	6. PIPE THINCKNESS
7. FLOW	7. LINING MATERIAL
8. IN/ OUTPUT	8. LINING SONIC V _s
9. DATA LOG	9. LINING THICKNESS
0. DIAG	0. SENSOR DISTANCE

3.1 Pipe – Flange Type

Always select 1.NONE if using **Clamp-On** type Ultrasonic Flowmeter. The setting of Flange is only for *insertion* type of Ultrasonic Flowmeter.

Press [MENU] – 3.PIPE – 1. FLAMGE TYPE

PIPE	FLANGE TYPE
1. FLANGE TYPE	1. NONE
2. PIPE UNIT	2. FT-12-200
3. PIPE MATERIAL	3. FT-12-300
4. PIPE SONIC V _s	4. FT-12-400
5. PIPE DIAMETER	5. FT-12-500
6. PIPE THINCKNESS	6. FT-12-600
7. LINING MATERIAL	7. FT-20-200
8. LINING SONIC V _s	8. FT-40-200
9. LINING THICKNESS	9. JFT-19
0. SENSOR DISTANCE	0. JFT-19-2

3.2 Pipe – Pipe Unit

User can select the unit for measuring either mm or inch.

Press [MENU] – 3.PIPE – 2. PIPE UNIT

- Metric (mm)
- US units (inch)

PIPE	PIPE UNIT
1. FLANGE TYPE	1. Metric (mm)
2. PIPE UNIT	2. US units (inch)
3. PIPE MATERIAL	
4. PIPE SONIC V _s	
5. PIPE DIAMETER	
6. PIPE THINCKNESS	
7. LINING MATERIAL	
8. LINING SONIC V _s	
9. LINING THICKNESS	
0. SENSOR DISTANCE	

3.3 Pipe – Pipe Material

Select the correct material of the operation pipe.

Press [MENU] – 3.PIPE – 3. PIPE MATERIAL

PIPE	PIPE MATERIAL
1. FLANGE TYPE	1. STEEL
2. PIPE UNIT	2. IRON
3. PIPE MATERIAL	3. DUCT ILE-IRON
4. PIPE SONIC V _s	4. CAST-IRON
5. PIPE DIAMETER	5. SUS
6. PIPE THINCKNESS	6. ALUMINUM
7. LINING MATERIAL	7. COPPER
8. LINING SONIC V _s	8. BRASS
9. LINING THICKNESS	9. PVC
0. SENSOR DISTANCE	0. FRP

3.4 Pipe – Pipe Sonic Vs.

Enter the sound velocity of the pipe material.

Press [MENU] – 3.PIPE – 4. PIPE SONIC Vs

- Input value with [NUM]
- Leave the edit mode by pressing [ENT].

PIPE	PIPE SONIC Vs
1. FLANGE TYPE	<div style="border: 1px solid black; padding: 5px; text-align: center;"> m/s ---- </div>
2. PIPE UNIT	
3. PIPE MATERIAL	
4. PIPE SONIC Vs	
5. PIPE DIAMETER	
6. PIPE THINCKNESS	
7. LINING MATERIAL	
8. LINING SONIC Vs	
9. LINING THICKNESS	
0. SENSOR DISTANCE	

3.5 Pipe – Pipe Diameter

Input the diameter of operation pipe.

Press [MENU] – 3.PIPE – 5. PIPE DIAMETER

- Input value with [NUM]
- Leave the edit mode by pressing [ENT].

PIPE	PIPE DIAMETER
1. FLANGE TYPE	<div style="border: 1px solid black; padding: 5px; text-align: center;"> UNIT :mm - - - - - </div>
2. PIPE UNIT	
3. PIPE MATERIAL	
4. PIPE SONIC Vs	
5. PIPE DIAMETER	
6. PIPE THINCKNESS	
7. LINING MATERIAL	
8. LINING SONIC Vs	
9. LINING THICKNESS	
0. SENSOR DISTANCE	

3.6 Pipe – Pipe Thickness

Input the thickness of operation pipe.

Press [MENU] – 3.PIPE – 6. PIPE THINCKNESS

- Input value with [NUM]
- Leave the edit mode by pressing [ENT].

PIPE	PIPE THINCKNESS
1. FLANGE TYPE	<div style="border: 1px solid black; padding: 5px; text-align: center;"> UNIT :mm - - - - - </div>
2. PIPE UNIT	
3. PIPE MATERIAL	
4. PIPE SONIC Vs	
5. PIPE DIAMETER	
6. PIPE THINCKNESS	
7. LINING MATERIAL	
8. LINING SONIC Vs	
9. LINING THICKNESS	
0. SENSOR DISTANCE	

3.7 Pipe – Lining Material

Input the thickness of lining.

Press [MENU] – 3.PIPE – 7. LINING MATERIAL

PIPE	LINING MATERIAL
1. FLANGE TYPE	<div style="border: 1px solid black; padding: 5px;"> 1. NONE 2. MORTAR 3. TAR-EPOXY 4. TEFLON 5. POLYETHYLENE 6. ENAMEL 7. GLASS 8. PLASTIC 9. RUBBER </div>
2. PIPE UNIT	
3. PIPE MATERIAL	
4. PIPE SONIC Vs	
5. PIPE DIAMETER	
6. PIPE THINCKNESS	
7. LINING MATERIAL	
8. LINING SONIC Vs	
9. LINING THICKNESS	
0. SENSOR DISTANCE	

3.8 Pipe – Lining Sonic Vs

Enter the sound velocity of the lining material.

Press [MENU] – 3.PIPE – 8.LINING SONIC Vs

- Input value with [NUM]
- Leave the edit mode by pressing [ENT].

PIPE	LINING SONIC Vs
1. FLANGE TYPE	<div style="border: 1px solid black; padding: 5px; text-align: center;"> m/s ---- </div>
2. PIPE UNIT	
3. PIPE MATERIAL	
4. PIPE SONIC Vs	
5. PIPE DIAMETER	
6. PIPE THINCKNESS	
7. LINING MATERIAL	
8. LINING SONIC Vs	
9. LINING THINCKNESS	
0. SENSOR DISTANCE	

3.9 Pipe – Lining Thickness

Input the thickness of operation pipe.

Press [MENU] – 3.PIPE – 9.LINING THINCKNESS

- Input value with [NUM]
- Leave the edit mode by pressing [ENT].

PIPE	LINING THINCKNESS
1. FLANGE TYPE	<div style="border: 1px solid black; padding: 5px; text-align: center;"> UNIT : mm - - - - - </div>
2. PIPE UNIT	
3. PIPE MATERIAL	
4. PIPE SONIC Vs	
5. PIPE DIAMETER	
6. PIPE THINCKNESS	
7. LINING MATERIAL	
8. LINING SONIC Vs	
9. LINING THINCKNESS	
0. SENSOR DISTANCE	

3.10 Pipe – Sensor Distance

After input above specifications, the flowmeter will count the Sensor Distance automatically. User doesn't need to change the value here.

Caution) The Correct sensor distance will show up automatically after user enter other pipes specifications.

Press [MENU] – 3.PIPE – 0.SENSOR DISTANCE


PIPE	SENSOR DISTANCE
1. FLANGE TYPE	<div style="border: 1px solid black; padding: 5px; text-align: center;"> UNIT : mm - - - - - </div>
2. PIPE UNIT	
3. PIPE MATERIAL	
4. PIPE SONIC Vs	
5. PIPE DIAMETER	
6. PIPE THINCKNESS	
7. LINING MATERIAL	
8. LINING SONIC Vs	
9. LINING THINCKNESS	
0. SENSOR DISTANCE	

Setting Operation – Liquid Characteristics

4. Liquid -

Before installing the flowmeter, set the liquid characteristics in the main menu to allow measurements. **Caution) Measurements cannot be accomplished without these settings.**

Press [MENU] – 4. LIQUID




4.1 Liquid – Liquid Material

Select the liquid type for measuring the flow.

Press [MENU] – 4. LIQUID – 1.LIQUID MATERIAL

- Water 20°C/40°C/60°C/75°C
- Gas




4.2 Liquid – Sonic Velocity

Enter the sound velocity of the operation liquid.

Press [MENU] – 4. LIQUID – 2. SONIC VELOCITY

- Input value with [NUM]
- Leave the edit mode by pressing [ENT].




4.3 Liquid – Viscosity

Enter the viscosity of the operation liquid.

Press [MENU] – 4. LIQUID – 3. VISCOSITY

- Input value with [NUM]
- Leave the edit mode by pressing [ENT].




4.4 Liquid – Density

Enter the density of the operation liquid.

Press [MENU] – 4. LIQUID – 4.DENSITY

- Input value with [NUM]
- Leave the edit mode by pressing [ENT].




Setting Operation – Installation

5. Install -

Before starting this section, please follow the directions in Section 3 and 4 to input the specifications of PIPE and LIQUID. ***Caution) This Section shall be review carefully before installation.***


Press [MENU] – 5. INSTALL



5.1 Install – Sensor Type

Choosing the correct type of transducer is extremely important. Each type of sensor measuring different size of pipes. User must select the right sensor type on the flowmeter for complete the installation.

Press [MENU] – 5. INSTALL – 1.SENSOR TYPE



5.2 Install – Sample CLK

Xonic 100 will select Sampling Clock automatically, user doesn't need to change it.


5.3 Install – Mounting Type

Please select the correct Mount Type on the flowmeter.

Caution) Please refer to Section --- for each Mounting modes' Descriptions.

Press [MENU] – 5. INSTALL – 3. MOUNT TYPE

- Clamp on Z type (refer to page 7.)
- Clamp on V type (refer to page 7.)
- Insertion Z type
- Insertion V type



5.4 Install –

The page shows on the flowmeter is for user to review the installation details.

Install Info

Press [MENU] – 5. INSTALL – 4. INSTALL INFO

INSTALL	INSTALL INFO
1. SENSOR TYPE	PIPE:STEEL
2. SAMPLING CLK	-OD:165.20mm
3. MOUNT TYPE	-T:5.00m
4. INSTALL INFO	Liner:None
5. AUTO INSTALL	-T:0.00m
6. QUICK INSTALL	Sensor:C type
7. ACTUAL ZERO	-Clk:20ns
	-Mnt:CLAMP_ON Z
	-SPACE:65.0mm

EUROMAG INTERNATIONAL S.r.l. www.euromag.com | www.euromagdata.com

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
 Tel. +39 049.9005064 | Fax +39 049.9007764
euromag@euromag.com | euromag@pec.it

P.IVA 02161920281 C.F. 01908330242
 N. CEE IT 02161920281, C.C.I.A.A. di Padova,
 Cap. Soc. € 98.900 i.v., R.E.A. n 211936




5.5 Install – Auto Install

Xonic 100P use its patented AR (Anti-Round) mode Ultrasonic Signal for flow measurement.

Press [MENU] – 5. INSTALL – 5.AUTO INSTALL

- 1) Select 1.NO by pressing [ENT] and back to 5.5 INSTALL menu.
- 2) Select 2.YES by pressing [ENT] to start Auto Installation.
(At this moment, user can see it start AR mode installation procedure. The screen will showing waved signals and “Search Wave Frequency”. It might take few minutes to find the best signals for flow measurement.)



- 3) After finishing installation, screen will show the Best Ultrasonic Signals.
Caution) The SHAPE of signal must be remembered carefully. The Best Ultrasonic Signals shall always have similar shape like above image.
- 4)

Check Points

 - Sound Vs: In case of measuring 20°C water, the sound speed shall be around 1480m/s.
 - Gain Level: It must be under 1500. However, the value of Gain Level is Higher than 1500, it means a Weakly Ultrasonic Signal.
 - Single Shape: The Best Ultrasonic Signal shall have the most spired shape in middle area.
- 5) If user has different result shows on the screen. Please check the specification of the installation site and re-check whether the setting on Flowmeter are exactly correct or not.

5.6 Install – Quick Install

The function is similar to Auto Install. But it is NOT suggest to be used by users, especially without technical suggestions from JAIN.


Press [MENU] – 5. INSTALL – 5.AUTO INSTALL

5.7 Install – Actual Zero

The function can help user to adjust the Zero Point on the flowmeter. If the screen doesn't show at zero point, when the flow is stopped. User can perform this function to do Zero Adjustment for the flowmeter.

Caution) Perform the function when the flow is stopped.

Press [MENU] – 5. INSTALL – 7. ACTUAL ZERO



Actual Zero User

Actual Zero User, is the automatic function to do actual zero by the software.

Press [MENU] – 4. INSTALL – 8. ACTUAL ZERO – 1. ACTUAL ZERO USER

- Press [ENT] to perform the function.
- The software will take about 30 second to reset the zero point for flowmeter
- After it finished, user will see a negative value in this menu.

Actual Zero Set

Actual Zero Set, is the manual function to do actual zero by user. Usually user will use the function after perform “Actual Zero User/Actual Zero Auto”. To clear the negative value.

Press [MENU] – 4. INSTALL – 8. ACTUAL ZERO – 2. ACTUAL ZERO SET

- Input the zero value with [NUM].
- Press [ENT] to save the data.

Actual Zero Reset

Actual Zero Reset, is the function to clear the data. Usually user will use the function after perform “Actual Zero User/Actual Zero Auto”. To clear the negative value.

Press [MENU] – 4. INSTALL – 8. ACTUAL ZERO – 3. ACTUAL ZERO RESET

- Press [ENT] to clear the data.

Actual Zero Auto

Actual Zero Auto, is the automatic function to do actual zero by the software when user is UNABLE to stop the flow.

Press [MENU] – 4. INSTALL – 8. ACTUAL ZERO – 4. ACTUAL ZERO AUTO


- Press [ENT] to perform the function.
- The software will take about 30 second to reset the zero point for flowmeter.
- After it finished, user will see a negative value in this menu.

Setting Operation – Operating Condition

6. Operate -

Before installing the transducer, set the operating condition in the main menu to allow measurements. ***Caution) Measurements cannot be accomplished without these settings.***

Press [MENU] – 6.OPERATE




6.1 Operate – Upper Flow Limit

Set the MAXIMUM measuring range of the flow so the software will measure the flow when not exceeds the limited flow rate.

Press [MENU] – 6.OPERATE – 1.UPPER FLOW LIMIT

- Input value with [NUM]
- Leave the edit mode by pressing [ENT].



6.2 Operate – Lower Flow Limit


Set the MINIMUM measuring range of the flow so that measuring rate will not lower than the limited flow rate.

6.3 Operate – Dead Zone

In the case of Dead Zond, it means flow rate being disregard, due to the big pipe operating with small flow. Then user can use the function for flow measurement. However, flowmeter will count the value automatically normally.

Press [MENU] – 6.OPERATE – 3.DEAD ZONE

- Default setting is 5 cubic feet per hour.
- Input value with [NUM]




6.4 Operate – Flow Average Set

The function displays the average flow of 5 seconds on the flowmeter. Default vaule is 5 seconds.

Press [MENU] – 6.OPERATE – 4. FLOW AVERAGE TIME

- Default setting is 5 seconds.
- Setup the average time in second with [[NUM]]




6.5 Operate – Total Flow Set

User can correct the total flow manually in this menu.

Press [MENU] – 6.OPERATE – 5.TOTAL FLOW SET

- Input value with [NUM]
- Leave the edit mode by pressing [ENT].




6.7.1 Operate – Alarm –

User can set the alrams for flow rates.

Press [MENU] – 6.OPERATE – 6.ALARAM


- Input value with [NUM]
- Leave the edit mode by pressing [ENT].



6.7 Operate – Calibration

The function is for people whom have calibration laboratory or experiences of calibrating to test the flowmeter. **Caution) User should not perform this function without manufacture's technical instruction.**


Press [MENU] – 6.OPERATE – 7. CALIBRATION



6.7.1 Operate – Calibration – Method

User can select the Calibration Method to calibrate the flowmeter.


Press [MENU] – 6.OPERATE – 7. CALIBRATION – 1. METHOD



6.7.2 Operate – Calibration – Mutli-Point Set

User can test the flow in the limited measuring ranges that user set at Menu 6.1 and 6.2. Then user can edit the points manually in this menu.

Press [MENU] – 6.OPERATE – 7. CALIBRATION – 2. MULTI-POINT SET




- Input value with [NUM]
- Leave the edit mode by pressing [ENT].

6.7.3 Operate – Calibration – Kc Set

The flow calibration with calibration factor.

Press [MENU] – 6.OPERATE – 7. CALIBRATION – 3. Kc SET




Ex)

- If Flow is 100, Kc is 1.0. The flow will be 100.
- A GC is “Automatic Gain Control”

6.8 Operate – Enable AGC

Press [MENU] – 6.OPERATE – 8. ENABLE AGC


- Default setting is ENABLE.



6.9 Operate – Damping

Damping functions to display the data smoothly.

Press [MENU] – 6.OPERATE – 9. DAMPING



6.10 Operate – Fix RISC

Xonic 100 will find the best RISC for the flow measurement.

Caution) User should not perform this function without manufacture's technical instruction.


Press [MENU] – 6.OPERATE – 0. FIX RISC

Setting Operation – Flow Parameters

7. Flow -

Before installing the transducer, set the flow parameters in the main menu to allow measurements.


Press [MENU] – 7. FLOW



7.1 Flow – Flow Volume Unit

User can select the unit for flow measurement on the list.


Press [MENU] – 7. FLOW – 1. FLOW VOLUME UNIT



7.2 Flow – Flow Time Unit

User can select the unit of measurement time on the list.

Press [MENU] – 7. FLOW – 2. FLOW TIME UNIT




7.3 Flow – Flow Resolution

User can select the decimal points on the list.

Press [MENU] – 7. FLOW – 3. FLOW RESOLUTION

Ex)


- xxxx. , means 10 for flow.
- xxx.x , means 10.1 for flow.
- xx.xx , means 10.12 for flow.



7.4 Flow – Flow Scale

In case of big flow, user can select Kilo on the list.


Press [MENU] – 7. FLOW – 4. FLOW SCALE



7.5 Flow – Total Volume Unit

User can select the unit for total flow on the list. Normally, the Setting of Total Volume will be same as Flow Unit.


Press [MENU] – 7. FLOW – 5. TOTAL VOLUME UNIT



7.6 Flow – Total Resolution

User can select the decimal points on the list.


Press [MENU] – 7. FLOW – 6. TOTAL RESOLUTION



7.7 Flow – Total Scale

User can select Kilo for big flow total.


Press [MENU] – 7. FLOW – 7. TOTAL SCALE



7.8 Flow – Batch Total

The internal batch controller in the system is able to control the input signals through keypad or analog input.

Press [MENU] – 7. FLOW – 8. BATCH TOTAL




7.9 Flow – Totalizer Mode

User can set the mode for totalize flow.

Press [MENU] – 6. FLOW – 9. TOTALIZER MODE

- Net Total - Default
(The software will totalize positive and negative flow automatically)
- Positive Total (Only totalize positive flow)
- Negative Total (Only totalize negative flow)



Input/output – Analog Out


8. In/Output -

Xonic 100 Series is available for 4-20m ADC output with two configurations. Also has two Relay for output and two configurations for input. User can assign each data individually with each configuration.

Caution) ONLY Analog Out [1] & Relay Out [1] is available for Xonic100P.

Press [MENU] – 8. IN/OUTPUT

- Analog Out [1]
- ~~Analog Out [2]~~
- Relay Out [1]
- ~~Relay Out [2]~~
- ~~Analog In [1]~~
- ~~Analog In [2]~~



8.1 In/Output – Analog Out [1]


The flowmeter has two analog output for 4-20m ADC. Both Analog Out [1] and Analog Out [2] has exactly same functions to output data.

8.1.1 In/Output – Analog Out [1] – Output Data

User can assign Flow or Velocity to Analog Out.

Press [MENU] – 8. IN/OUTPUT – 1. ANALOG OUT [1] –
1. OUTPUT DATA

- None – Disable Output Function
- Output the Flow Data
- Output the Velocity Data




8.1.2 In/Output – Analog Out [1] – Output Mode

User shall use the default setting, by application.

Press [MENU] – 8. IN/OUTPUT – 1. ANALOG OUT [1] –
2. OUTPUT MODE

- By Application – Set Up by the program.
- [CH 1] only – Channel/Site 1



8.1.3 In/Output – Analog Out [1] – Calibration_Min

Caution) Do NOT use this function without manufacture's technical instructions.

Press [MENU] – 8. IN/OUTPUT – 1. ANALOG OUT [1] – 3. CALIBRATION_MIN

8.1.4 In/Output – Analog Out [1] – Calibration_Max

Caution) Do NOT use this function without manufacture's technical instructions.


Press [MENU] – 8. IN/OUTPUT – 1. ANALOG OUT [1] – 4. CALIBRATION_MAX

8.1.5 In/Output – Analog Out [1] – Span Min

User can use this menu to set the Span Minimum for the flow.

Press [MENU] – 7. IN/OUTPUT – 1. ANALOG OUT [1] –
5. SPAN_MIN

- The value should be same with the minimum flow user set in the menu, 6.2 Lower Flow Limit.




8.1.6 In/Output – Analog Out [1] – Span Max

User can use this menu to set the Span Maximum for the flow.

Press [MENU] – 7. IN/OUTPUT – 1. ANALOG OUT [1] –
6. SPAN MAX

- The value should be same with the maximum flow user set in the menu, 6.1 Upper Flow Limit.



8.1.7 In/Output – Analog Out [1] – 2mA Set

Caution) Do NOT use this function without manufacture's technical instructions.

Press [MENU] – 7. IN/OUTPUT – 1. ANALOG OUT [1] – 7. 2mA Set

Input/output – Relay Out

8.3 In/Output – Relay Out [1]

In this section, user can know how to set for Relay Output. User can assign each data with Relay Out [1] and [2] individually.


Press [MENU] – 8. IN/OUTPUT – 3.RELAY OUT [1]

8.3.1 In/Output – Relay Out [1] – Output Data

Select the data for Relay Out.

Press [MENU] – 8. IN/OUTPUT – 3.RELAY OUT [1] –
1. OUTPUT DATA

- Relay Off: Disable
- Relay On: Enable
- High Flow only




8.3.2 In/Output – Relay Out [1] – Output Mode

User shall use the default setting, by application.

Press [MENU] – 7. IN/OUTPUT – 3.RELAY OUT [1] –
2. OUTPUT MODE

- By Application – Set Up by the program.
- [CH 1] only – Not available for Open Channel
- [CH 2] only – Not available for Open Channel




8.3.3 In/Output –

Relay Out [1] – Duty Set

Press [MENU] – 8. IN/OUTPUT
– 3. RELAY OUT [1] – 3. DUTY SET


- Input value with [NUM]
- Leave the edit mode by pressing [ENT].



8.3.4 In/Output –

Relay Out [1] – Rev

Press [MENU] – 8. IN/OUTPUT
– 3. RELAY OUT [1] – 4. REV



Data Logger – Instructions

9. Data Log -

Xonic 100 P provides RS-232C for the communication.

Caution) Before user start logging data, user should review this section carefully.


➤ Please refer to page 9 for Data logger instructions.

9.1 Data Log – Time Set

User must setup the correct date and time for recording the measurement.

Press [MENU] – 9.DATA LOG – 1.TIME SET

- Move cursor by [◀] [▶].
- Input numbers by [NUM].
- Delete characters by [CLR].
- Leave the edit mode by pressing [ENT].




Data logger - RS-232C

9.2.1 Data Log – RS-232C – Configure

User should complete the Configure Setting for data logger.


Press [MENU] – 8.DATA LOG – 2.RS-232C
– 1.CONFIGURE




9.2.1.1 Data Log – RS-232C – Configure – Baud Rate

User can select the baud rate of the flow.


Press [MENU] – 9.DATA LOG – 2.RS-232C
– 1.CONFIGURE – 1.BAUD RATE




9.2.1.2 Data Log – Selecting data bits for RS-232C data logger.
RS-232C –
Configure – Press [MENU] – 9.DATA LOG – 2.RS-232C
Data Bits – 1.CONFIGURE – 2.DATA BITS




9.2.1.3 Data Log – Press [MENU] – 9.DATA LOG – 2.RS-232C
RS-232C – 1.CONFIGURE – 3. PARITY
Configure –
Parity



9.2.1.4 Data Log – Press [MENU] – 9.DATA LOG – 2.RS-232C
RS-232C – 1.CONFIGURE – 4.STOP BITS
Configure –
Stop Bits



9.2.1.5 Data Log – Press [MENU] – 9.DATA LOG – 2.RS-232C
RS-232C – 1.CONFIGURE – 5.LINE FEED
Configure –
Line Feed




9.2.1.6 Data Log – RS-232C – Configure – Network ID

User can set a ID in order to identify.

Press [MENU] – 9.DATA LOG – 2.RS-232C– 1.CONFIGURE –
6. NETWORK ID

- Move cursor by [◀] [▶].
- Input alphabet characters by [F1].
- Delete characters by [CLR].
- Leave the edit mode by pressing [ENT].




9.2.2 Data Log – RS-232C – Header

User can set a Header as a Network ID for the communication.

Press [MENU] – 9.DATA LOG – 2.RS-232C– 2. HEADER

- Move cursor by [◀] [▶].
- Input alphabet characters by [F1].
- Delete characters by [CLR].
- Leave the edit mode by pressing [ENT].




9.2.3 Data Log – RS-232C – Format

User can add and list the data here so th data will be download sequentially.

Press [MENU] – 9.DATA LOG – 2.RS-232C– 3.FORMAT

- Move cursor by [◀] [▶].
- Input alphabet characters by [F1].
- Delete characters by [CLR].
- Leave the edit mode by pressing [ENT].




9.2.4 Data Log – RS-232C – Separator

User can select Space, Comma or Tab to separate the data.

Press [MENU] – 9.DATA LOG – 2.RS-232C
– 4.SEPARATOR


- Move cursor by [◀] [▶].
- Input alphabet characters by [F1].
- Delete characters by [CLR].
- Leave the edit mode by pressing [ENT].



9.2.5 Data Log – RS-232C – Log Interval

The Log Interval is the measurement period of time which are taken by the transducers. **Caution) If the flow value changes rapidly, then the log interval time needs to be rapidly as well.**

Press [MENU] – 9.DATA LOG – 2.RS-232C
– 5.LOG INTERVAL




9.2.6 Data Log – RS-232C–Log Time Sync

Press [MENU] – 9.DATA LOG – 2.RS-232C – 6.LOG TIME SYNC

9.2.7 Data Log – RS-232C – Log Enable

User must enable the function for data logger.

Press [MENU] – 9.DATA LOG – 2.RS-232C
– 7.LOG ENABLE




9.2.8 Data Log – RS-232C – Comm Mode

User must enable the function for data logger.

Press [MENU] – 8.DATA LOG – 2.RS-232C –
8. COMM MODE


- Normal – Default
- Call Answer – Only available in local
- CDMA Comm – CDMA Communication
- MODBUS RTU – MODBUS Communication



9.2.9 Data Log – RS-232C – Select Comm

User can use both cable RS-232 and RS-485 to for the communication.

Press [MENU] – 9.DATA LOG – 2.RS-232C
– 9.SELECT COMM




Data Logger - Memory

9.3.1.1 Data Log – Memory – Log Output – Log Date

User can see the records of First Log and Last Log here.


Press [MENU] – 9.DATA LOG – 3.MEMORY
– 1. LOG OUTPUT – 1. LOG DATE



9.3.1.2 Data Log – Memory – Log Output – Log Output

User can set period of data to output here.

Press [MENU] – 9.DATA LOG – 3.MEMORY
– 1. LOG OUTPUT – 2.LOG OUTPUT




➤ Move cursor by [◀] [▶].

➤ Input date by [NUM].

9.3.2 Data Log – Memory – Format

User can add and list the data here so the data will be download sequentially.

Press [MENU] – 9.DATA LOG – 3.MOMERY - 3.FORMAT



➤ Move cursor by [◀] [▶].

➤ Input alphabet characters by [F1].


➤ Delete characters by [CLR].

➤ Leave the edit mode by pressing [ENT]

9.3.3 Data Log – Memory – Log Interval

The Log Interval is the measurement period of time which are taken by the transducers. **Caution)If the flow value changes rapidly, then the log interval time needs to be rapidly as well.**

Press [MENU] – 9.DATA LOG – 3.MEMORY
– 5.LOG INTERVAL



8.2.6 Data Log–RS-232–

Log Time Sync

Press [MENU] – 8 DATA LOG – 2 RS-232C – 6 LOG TIME SYNC

EUROMAG INTERNATIONAL S.r.l. www.euromag.com | www.euromagdata.com

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
Tel. +39 049.9005064 | Fax +39 049.9007764
euromag@euromag.com | euromag@pec.it


P.IVA 02161920281 C.F. 01908330242
N. CEE IT 02161920281, C.C.I.A.A. di Padova,
Cap. Soc. € 98.900 i.v., R.E.A. n 211936



9.3.5 Data Log – Memory – Log Enable

User must enable the function for data logger.


Press [MENU] – 9.DATA LOG – 3.MEMORY
– 5.LOG ENABLE



9.3.6 Data Log – Memory – Port Select

User can use both RS-232 port or Firmware port to connect flowmeter with user's laptops. **Caution) The setting must be correct otherwise use is unable to download the data.**


Press [MENU] – 9.DATA LOG – 3.MEMORY
– 6. PORT SELECT



9.3.7 Data Log – Memory – Memory Clear

User can clear all of data and setting in here.

Press [MENU] – 9.DATA LOG – 3.MEMORY
– 7. MEMORY CLEAR



Wave Data

EUROMAG INTERNATIONAL S.r.l. www.euromag.com | www.euromagdata.com

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
Tel. +39 049.9005064 | Fax +39 049.9007764
euromag@euromag.com | euromag@pec.it


P.IVA 02161920281 C.F. 01908330242
N. CEE IT 02161920281, C.C.I.A.A. di Padova,
Cap. Soc. € 98.900 i.v., R.E.A. n 211936



9.4 Data Log – Wave Data

Download the Signal Wave Data.

Press [MENU] – 9.DATA LOG – 4.WAVE DATA



EUROMAG INTERNATIONAL S.r.l. www.euromag.com | www.euromagdata.com

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
Tel. +39 049.9005064 | Fax +39 049.9007764
euromag@euromag.com | euromag@pec.it

P.IVA 02161920281 C.F. 01908330242
N. CEE IT 02161920281, C.C.I.A.A. di Padova,
Cap. Soc. € 98.900 i.v., R.E.A. n 211936




Diagnostics Menu

10. Diag -

User can review more information about the measurement in this menu.

Caution) The setting shall not be modify without manufacture's technical support.


Press [MENU] – 9.DIAG



10.1 Diag – Frequency Div

Caution) The setting shall not be modify without manufacture's technical support.

Press [MENU] – 9.DIAG – 1.FREQUENCY DIV




10.2 Diag – Risc

RISC is the distance from impulse signal to receive signal.

Caution) The setting shall not be modify without manufacture's technical support.


Press [MENU] – 9.DIAG – 2.RISC



10.3 Diag – Pulse Count

Set Once or Limit for Pulse Count.

Press [MENU] – 9.DIAG – 3.PULSE COUNT



EUROMAG INTERNATIONAL S.r.l. www.euromag.com | www.euromagdata.com

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
 Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
 Tel. +39 049.9005064 | Fax +39 049.9007764
 euromag@euromag.com | euromag@pec.it

P.IVA 02161920281 C.F. 01908330242
 N. CEE IT 02161920281, C.C.I.A.A. di Padova,
 Cap. Soc. € 98.900 i.v., R.E.A. n 211936



Once

Once set for pulse count.


Limit

Enable or Disable the Limited for pulse count.

10.4 Diag – Gain Level

Gain Level is amplitude level of signal. The value will be set and calculated automatically by the flowmeter.

Press [MENU] – 9.DIAG – 4.GAIN LEVEL




10.5 Diag – Hold Flow

The function is for matching with remote indicator. User can use this menu to test Analog Output's function.


Press [MENU] – 9.DIAG – 5.HOLD FLOW

Ex) Analog out - SPAN MIN: 0 / SPAN MAX: 1000

- When user set HOLD FLOW at 0, flowmeter shall send 4mA signal to Analog Output.
- When user set HOLD FLOW at 1000, flowmeter shall send 20mA signal to Analog Output.



Drawings




EUROMAG INTERNATIONAL S.r.l. www.euromag.com | www.euromagdata.com

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
 Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
 Tel. +39 049.9005064 | Fax +39 049.9007764
 euromag@euromag.com | euromag@pec.it


P.IVA 02161920281 C.F. 01908330242
 N. CEE IT 02161920281, C.C.I.A.A. di Padova,
 Cap. Soc. € 98.900 i.v., R.E.A. n 211936





COMMUNICATION	
PIN NO#	COLOR
1	VIOLET
2	BROWN
3	GREEN
4	BLUE
5	BLACK
6	WHITE
7	GRAY
8	YELLOW
9	ORANGE
10	RED



CHANNEL 1	
PIN NO#	BOARD PIN
1	BNC 801.4
2	BNC 801.2
3	BNC 802.4
4	BNC 802.2



CHANNEL 2	
PIN NO#	BOARD PIN
1	BNC 803.4
2	BNC 803.2
3	BNC 804.4
4	BNC 804.2



Xonic-100P Flow Computer

DATE	DWG NAME	Xonic-100P Flow computer
DRAWING	PROJECT NAME	INSULATOR
DESIGNED	SCALE	DWG NO.
CHECKED	REV	
SUPERY		



EUROMAG INTERNATIONAL S.r.l. www.euromag.com | www.euromagdata.com

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
Tel. +39 049.9005064 | Fax +39 049.9007764
euromag@euromag.com | euromag@pec.it

P.IVA 02161920281 C.F. 01908330242
N. CEE IT 02161920281, C.C.I.A.A. di Padova,
Cap. Soc. € 98.900 i.v., R.E.A. n 211936




Xonic-100P MODELS



Power Adapter / Battery Charger

DATE		DWG NAME	Xonic-100P Flow computer
DRAWING		PROJECT NAME	POWER ADAPTER/BATTERY CHARGER
DESIGNED		SCALE	DWG. NO.
CHECKED			REV.
SUPERV.			



Xonic-100P MODELS

TRANSDUCER CABLE DETAILS


DATE		DWG NAME	Xonic-100P Flow computer
DRAWING		PROJECT NAME	TRANSDUCER INSTALLATION
DESIGNED		SCALE	DWG NO.
CHECKED			REV
SUPERV			

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
 Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
 Tel. +39 049.9005064 | Fax +39 049.9007764
 euromag@euromag.com | euromag@pec.it

P.IVA 02161920281 C.F. 01908330242
 N. CEE IT 02161920281, C.C.I.A.A. di Padova,
 Cap. Soc. € 98.900 i.v., R.E.A. n 211936




REFLECT MODE INSTALLATION




DATE	DWG NAME	TRANSDUCERS INSTALLATION AND MOUNTING TRACKS (REFLECT MODE)	SCALE	DWG NO.	102-TP	REV
DRAWING	DESIGNED	PROJECT NAME	CHECKED	SUPERV		

DIRECT MODE INSTALLATION



DATE	DWG NAME	TRANSUCERS INSTALLATION AND MOUNTING TRACKS(DIRECT MODE)	SCALE	DWG NO.	100-TP	REV
DRAWING	PROJECT NAME		CHECKED			
DESIGNED			SUPERV			




TRANSDUCER

APPLY A THIN BAND OF COUPLANT
TO THE BASE OF EACH TRANSDUCER
BEFORE INSTALLING ON PIPE

USE OF COUPLANT COMPOUND

DATE		DWG NAME	TRANSDUCERS INSTALLATION COUPLANT	REV
DRAWING		PROJECT NAME		
DESIGNED		SCALE	DWG NO.	102-C
CHECKED				
SUPPLY				

TRANSDUCER CONNECTOR KIT



DATE		DWG NAME	TRANSDUCER CONNECTOR KIT	REV
DRAWING		PROJECT NAME		
DESIGNED		SCALE	DWG NO.	
CHECKED				
SUPERY				

EUROMAG INTERNATIONAL S.r.l. | www.euromag.com | www.euromagdata.com

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
 Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
 Tel. +39 049.9005064 | Fax +39 049.9007764
 euromag@euromag.com | euromag@pec.it

P.IVA 02161920281 C.F. 01908330242
 N. CEE IT 02161920281, C.C.I.A.A. di Padova,
 Cap. Soc. € 98.900 i.v., R.E.A. n 211936



EUROMAG INTERNATIONAL S.r.l. www.euromag.com | www.euromagdata.com

Sede legale e stabilimento: Via Torino 3 | 35035 Mestrino (Padova), Italia
Sede operativa: Via Pitagora 20 | 35030 Rubano (Padova), Italia
Tel. +39 049.9005064 | Fax +39 049.9007764
euromag@euromag.com | euromag@pec.it

P.IVA 02161920281 C.F. 01908330242
N. CEE IT 02161920281, C.C.I.A.A. di Padova,
Cap. Soc. € 98.900 i.v., R.E.A. n 211936

